


Note:

The equipment will shut down automatically if there is no button press for 60 seconds. It defaults to the current setting after rebooting, while it will save previous settings in case of power failure.

4.7 Measurement

Put the slide switch in the measurement mode, press the "switch measurement" button to turn on the thermometer, point the thermometer sensor head at the object to be measured, press the "switch measurement" button, and hear a beep after about 1S. "bi" sound (no sound if the sound is turned off) indicates that the temperature has been measured, and the test result is displayed on the LCD screen.



Note:

When the measured temperature is $< 40.0^{\circ}\text{C}$, the LCD backlight is green; when the measured temperature is $\geq 40.0^{\circ}\text{C}$, the LCD backlight is green red and gives a warning with sound of "Bi", "Bi", "Bi".


4.9 Memory query

Press the button "Memory" to start up the thermometer, the screen displays "---- M" and the symbol "M" flashes. Press the button "Memory" again to display the number of memory groups + M icon, and about 1 second later, show the display memory value + the symbol "M" flashes.



4.8 Calibration

Set the slide switch to the calibration mode, press the "Switch measurement" key to turn on, point the thermometer head at the object to be measured, press the "switch measurement" key button, and hear a "bi" sound after about 1S. If the sound is turned off, it will not sound) means that the surface temperature of the object has been measured, and the test result is displayed on the LCD screen.




4.10 Memory deletion

In shutdown mode, press and hold the button "Memory", the sound setting appears 4 seconds later at first, and keep holding to clear the memory value 8 seconds later, at this time, it shows "CLr + M", which flashes with the sound of "Bi-Bi-Bi". After clearing, the equipment will shut down automatically.



4.11 Low battery indicator

When the battery voltage is below 2.60V, only the low-voltage symbol will appear after starting up, and it cannot be used for measurement before replacement of the battery.



4.12 Shutdown

The equipment will shut down automatically if there is no operation for 60 seconds.

5.3 Ambient temperature out of range

Error message on screen	Meaning of show	Possible causes and solutions
ErL	The ambient temperature is lower than 5°C	Move to another warm room
ErH	The ambient temperature is higher than 40°C	Move to another cold room

Chapter 5 Troubleshooting

5.1 Measured temperature too high

Error message on screen	Meaning of show	Possible causes and solutions
H1	Measured temperature is too high (above 42.9°C)	The result exceeds the measurement range limit.
H2	Calibration measurement temperature is too high (above 100°C)	The result exceeds the measurement range limit.

5.2 Measured temperature too low

Error message on screen	Meaning of show	Possible causes and solutions
L0	Measuring temperature is too low (below 32.0°C)	The result exceeds the measurement range limit.
L1	Calibration measurement temperature is too low (below 0°C)	The result exceeds the measurement range limit.

Chapter 6 Cleaning and Maintenance

Clean with a dry soft cloth. If the engine is particularly dirty, wipe with a wet and wrung out cloth and then dry it with a dry cloth. Disinfect the product only when necessary; disinfection is recommended to carry out by wiping the product surface twice with disinfectant. Do not soak or use gas for disinfection. Use medical alcohol is recommended. If necessary, when repeatedly measuring the temperature, please clean the infrared thermometer first. Use an alcohol cotton swab or a cotton ball dipped in alcohol (70% alcohol) to clean the infrared thermometer case and temperature head, taking care to avoid liquid from entering the infrared measurement. Do not use corrosive cleaning agents, thinners or benzene solvents inside the thermometer, and do not immerse the infrared thermometer in water or other cleaning solutions.

Do not expose the equipment to high temperature, high humidity, dust or direct sunlight.

Remove the battery when the thermometer will not be used for a long time.

Buyer Pro Network
TİCARET